

CHEMICAL INFORMATION

GON – Is a metal and stain eliminator. Gon removes the metal & stain found in water such as iron, copper & manganese. Gon should circulate in a filled spa for at least 30 minutes before balancing water.

Chlor – Granular concentrated sanitizer (chlor) made to be used in your Softub. Use as needed to keep water fresh. Use 2 T or more a week. With well water you will use more chlor, and with city water less because it contains chlorine.

Ph up-Ph down – If Ph up is low, add Ph up and if it is high, add Ph down. Do this gradually by adding a tablespoon at a time. Keeping the PH in the proper range will significantly lengthen the life of your liner.

Insta-4 Test Strips (50ct.) – Used to test Free Chlorine, Alkalinity, PH

Spa Frog – Spa frog is a mineral purifier which helps kill bacteria & algae. Fits inside filter and slowly releases unique metallic ions into the water that help control microbial contamination, which reduces the demand on the sanitizer (chlor).

Filter – Change filter around once a year. Clean filter at least twice a month.

Barrier Filter (Upgrade) – Change around once a year. This filter is microban antimicrobial protection inhibits the growth of bacteria

Filter Renu - Use monthly to clean and extend life of the filter. Spray your filter and rinse with water. It will clean out the rust etc.

Softub Skin Cleanser & Conditioner (Exterior) – Protect your Softub. Periodic cleaning and conditioning treatment keeps vinyl soft and restores UV protection.

Fragrance Crystals – There are a variety of scents and aromatherapy that are designed for your Softub. These will not change the water balance in your tub.

Defoam – This chemical rids your spa of excess foam that may be caused by soap, shampoo, cleaners and other residues that may be carried into your Softub.

Spa Perfect – This is a natural enzyme that reduces water line ring, clogged filters, etc. by breaking down body oils, lotions and hair oils as well as other contaminants in the water. Use 1 cap once a week.

Duramitt - Removes calcium and scum at water line and other stains with ease.

PH-Lock – Used to lock PH in the desired range. Don't use until PH is in the OK area of your Insta-4 test strips.

Spa Vac – Easily suctions debris out of Softub. No electric needed.

Swirl Away – Plumbing Cleaner. Dissolves body oil & chemical residue that builds up in plumbing and impair jet action. Use before draining Softub.